

How to start?

Online development

This is the easiest way to use RoboCORE. You only need to connect RoboCORE with RoboCORE Platform. There are 3 types of devices which can provide the Internet connection between RoboCORE and the RoboCORE Platform. \\Choose the one which you are going to use:



(you will be redirected to the more detailed instruction for each method).

Offline development

All instructions how to develop RoboCORE locally are available [here](#).