

How to start?

Online development (via RoboCORE Platform)

This is the easiest way to use RoboCORE. You only need to connect RoboCORE with RoboCORE Platform. There are 3 types of devices which can provide the Internet connection between RoboCORE and the RoboCORE Platform.

Connecting RoboCORE to the Internet

Choose the one which device are you going to use with RoboCORE:



(you will be redirected to the more detailed instruction for each method). Please remember that you can connect RoboCORE with Platform using Android device, iOS device or Intel Edison but you cannot use 2 of them at the same time.

Connecting RoboCORE to the cloud platform

[Connecting RoboCORE to the cloud platform](#)

Offline development

All instructions how to develop RoboCORE locally are available [here](#).